

I) Common-Ion Effect

Shift in equil. due to addition of an ion involved in the equil. system.

A) Addition of Strong Electrolyte



1) Add HCl

2) Add NaF

3) Ex1: What is $[OH^-]$ in a soln. made by dissolving 0.020 mole of NH_4Cl in 100.0 mL of 0.15M NH_3 ?

$$K_b = 1.8 \times 10^{-5}$$



init.
chg.
equil.

$$K_b = \frac{[NH_4^+][OH^-]}{[NH_3]}$$

B) Common-Ions from Acid-Base Rx's

Common-Ion generated by an acid-base neutralization rx.



Rx. goes to completion

Generally, rx's between the following proceed to completion

- strong acids & strong bases
- strong acids & weak bases
- weak acids & strong bases

Neutralization rx. produces a stoichiometric amt. of F^- , leaving excess HF

- have common-ion equil. calc.

Do stoichiometry calc. for neutralization rx. in moles & then convert to Molarity for the common-ion calc.

Do **NOT** Forget Dilution when appropriate

1) Ex 2: Calc. the pH of a soln.
produced by mixing 100.0 mL of
0.70 M NH_3 w. 100.0 mL of 0.40 M HCl .


a) Step 1: Neutralization rx. calc.
stoichiometry calc.

- convert to moles

$$\# \text{ moles} = V \cdot M$$

$$\text{moles } \text{NH}_3 = (0.1000 \text{ L}) \left(\frac{0.70 \text{ mol}}{\text{L}} \right) = 0.070 \text{ mol}$$

$$\text{moles } \text{H}^+ = (0.1000 \text{ L}) \left(\frac{0.40 \text{ mol}}{\text{L}} \right) = 0.040 \text{ mol}$$



b) Step 2: Common-Ion Calc.

Convert moles to Molarity

- Dilution

Now have 200.0 mL soln.

$$\text{Molarity } \text{NH}_3 = \frac{0.030 \text{ mol}}{0.2000 \text{ L}} = 0.15 \text{ M}$$

$$\text{Molarity } \text{NH}_4^+ = \frac{0.040 \text{ mol}}{0.2000 \text{ L}} = 0.20 \text{ M}$$

Proceed as in Ex. 1

II) Buffers

Solutions that resist a significant change in pH when small amounts of strong acid or base are added.

A) Composition & Action of Buffers

Contain both members of
Conjugate Weak Acid-Base Pair

Acid: reacts w. added base

Base: reacts w. added acid

Conj. A-B do NOT react w. each other



1) How it Works



$$K_a = \frac{[H^+][B^-]}{[HB]}$$

$$[H^+] = K_a \frac{[HB]}{[B^-]}$$

a) Add strong acid:



$[HB]$ Inc., $[B^-]$ Dec., chg. $\frac{[HB]}{[B^-]}$ small

$\therefore \Delta pH$ small

b) Add strong base:



$[HB]$ ↓, $[B^-]$ ↑, $\Delta \frac{[HB]}{[B^-]}$ & ΔpH small

B) Henderson - Hasselbalch Eq.

1) Weak Acid / Salt of Acid



$$[H^+] = K_a \frac{[HB]}{[B^-]}$$

$$-\log [H^+] = -\log K_a - \log \left(\frac{[HB]}{[B^-]} \right)$$

$$pH = pK_a + \log \left(\frac{[base]}{[acid]} \right)$$

Note:

$$[base]_{eq} = [base]_0 + [H^+]_{eq} \approx [base]_0$$

$$[acid]_{eq} = [acid]_0 - [H^+]_{eq} \approx [acid]_0$$

$$pH = pK_a + \log \left(\frac{[base]_0}{[acid]_0} \right)$$

c) Choosing a Buffer System

To be **effective**, the **ratio** of **components** **must** be between $\frac{10}{1}$ & $\frac{1}{10}$

$$\text{pH} = \text{pK}_a + \log\left(\frac{10}{1}\right) = \text{pK}_a + 1$$

$$\text{pH} = \text{pK}_a + \log\left(\frac{1}{10}\right) = \text{pK}_a - 1$$

\therefore **pK_a** of **acid** **must** be **within 1 unit** of **desired pH**

Note:

If **equal amts.** of the **2 components** are present

$$\text{pH} = \text{pK}_a$$

D) Calculations

1) Ex. 3: What is the pH of a buffer containing 0.10M HF & 0.25M NaF?

$$K_{a, HF} = 6.8 \times 10^{-4}$$

$$pK_a =$$

$$pH = pK_a + \log\left(\frac{[]}{[]}\right)$$

2) Ex. 4: What is the pH of a buffer containing 0.15 M NH_3 & 0.20 M NH_4Cl ?

$$K_{b, \text{NH}_3} = 1.8 \times 10^{-5}$$

$$pK_b = 4.74$$

3) Ex. 5: Calc. pH of 100.0 mL of Ex 1 $\text{NH}_3/\text{NH}_4^+$ buffer soln. to which 10.0 mL of 0.10 M NaOH is added. Compare to pH change if base is added to water.

a) Neutralization rx. calc. (moles)




init.	0.0010	0.020	0.015
chg.	-0.0010	-0.0010	+0.0010
compl.	0	0.019	0.016

Total Volume = 110.0 mL

$$[\text{NH}_4^+] = \frac{0.019 \text{ mol}}{0.1100 \text{ L}} = 0.173 \text{ M}$$

$$[\text{NH}_3] = \frac{0.016 \text{ mol}}{0.1100 \text{ L}} = 0.145 \text{ M}$$

b) Equilibrium - Buffer



$$\text{pH} = \text{pK}_a + \log\left(\frac{[\text{NH}_3]}{[\text{NH}_4^+]}\right)$$

$$\text{pH} = 9.26 + \log\left(\frac{0.145}{0.173}\right)$$

$$\text{pH} = 9.18$$

The buffer soln. had $\text{pH} = 9.13$
- change in pH of only 0.05

c) In pure H_2O

Add 10.0 mL of 0.10 M NaOH to $100.0 \text{ mL H}_2\text{O}$

$$\frac{0.0010 \text{ mol}}{0.1100 \text{ L}} = 0.0091 \text{ M OH}^-$$

$$\text{pOH} = 2.04 \qquad \text{pH} = 11.96$$

- change of almost 5 pH units

4) Ex. 6: What ratio of conc. should be used to prepare a formic acid/formate ion buffer having a pH of 4.0?

$$K_a = 1.8 \times 10^{-4}$$

III) Acid-Base Titrations

Titration: Procedure for determining *amt.* of *acid* (or *base*) in a *soln.* by reacting it w. an *equivalent* (*stoichiometric*) *amt.* of *base* (or *acid*).

Acid-Base Titration Curve


graph of *pH* vs.

volume of titrant added.

Equivalence Pt:



Transparency 119 Figure 17.5 pH curve for strong acid-strong base titration



A) Strong Acid-Strong Base Titration

Titration of 50.0 mL of
0.100 M HCl w. 0.100 M NaOH



Net Ionic Eq.:



1) Start: Before adding NaOH


$$[\text{H}^+] = 0.100 \text{ M}$$

$$\text{pH} = 1.00$$

2) Add 25.0 mL of NaOH

$$\# \text{ moles } H^+ = 0.0500L \times \frac{0.100 \text{ mol}}{L} = 0.00500$$

$$\# \text{ moles } OH^- = 0.0250L \times \frac{0.100 \text{ mol}}{L} = 0.00250$$



Excess H^+ in 75.0 mL

$$[H^+] = \frac{0.00250 \text{ mol}}{0.0750 L} = 0.0333 M$$

$$pH = 1.477$$

3) Add another 25.0 mL NaOH

Total Vol. NaOH = 50.0 mL

0.00500 mol H^+ 0.00500 mol OH^-

Equivalence Pt.

Have only NaCl in H_2O

pH =

4) What Indicator Should be Used?

a) 49.9 mL of NaOH

$$0.0499 \text{ L} \times \frac{0.100 \text{ mol}}{1 \text{ L}} = 0.00499 \text{ mol OH}^-$$

$$\text{Excess H}^+ = 1 \times 10^{-5} \text{ mol}$$

$$[\text{H}^+] = \text{—————} =$$

$$\text{pH} =$$

b) 50.1 mL of NaOH

$$\text{Excess OH}^- = 1 \times 10^{-5} \text{ mol}$$

$$[\text{OH}^-] = \text{—————} =$$

$$\text{pOH} =$$

$$\text{pH} =$$

c) Indicator


Region around eq. pt. is
long & steep

pH range 4.0 - 10.0

Any indicator that changes
color between 4.0 - 10.0
will signal end pt.
of titration

Indicator	pK_a
methyl red	5.3
bromthymol blue	6.8
thymol blue	8.8
phenolphthalein	9.1
methyl orange	4.0
m-cresol purple	8.0
indigo carmine	12.0
bromthymol blue	7.0

5) Strong Base - Strong Acid Titration



B) Weak Acid- Strong Base

(1) Higher initial pH

(2) pH rises more rapidly in early part of titration, but more slowly near eq. pt.


The weaker the acid, less marked Δ pH near eq. pt.

(3) pH \neq 7.0 at eq. pt.

pH at eq. pt. due to hydrolysis of resultant salt soln.

Transparency 121

Figure 17.9 Influence of acid strength on the shape of the titration curve




Ex 8: Titration of 50.0 mL of 0.100 M $\text{HC}_2\text{H}_3\text{O}_2$ w. 0.100 M NaOH .

1) Start: weak acid ionization




2) Add 25.0 mL of NaOH



Transparency 120

Figure 17.8 pH curve for weak acid-strong base titration



$$[\text{HC}_2\text{H}_3\text{O}_2] = \frac{0.00250 \text{ mol}}{0.0750 \text{ L}} = 0.0333 \text{ M}$$

$$[\text{C}_2\text{H}_3\text{O}_2^-] = \frac{0.00250 \text{ mol}}{0.0750 \text{ L}} = 0.0333 \text{ M}$$

Buffer!!!

$$\text{pH} = \text{pK}_a + \log \frac{[\text{C}_2\text{H}_3\text{O}_2^-]}{[\text{HC}_2\text{H}_3\text{O}_2]}$$

$$= 4.745 + \log \frac{(0.0333)}{(0.0333)}$$

$$= 4.745 + 0$$

$$\text{pH} = 4.745$$

NOTE: Halfway to eq. pt.

$$\text{pH} = \text{pK}_a$$


3) Add another 25.0 mL NaOH

Total Vol. NaOH = 50.0 mL


Equivalence Pt.


- converted ALL $\text{HC}_2\text{H}_3\text{O}_2$
to $\text{C}_2\text{H}_3\text{O}_2^-$

Hydrolysis!!



Need $[\text{C}_2\text{H}_3\text{O}_2^-]$ eq. pt.





$$K_b = \frac{K_w}{K_a} = \frac{1.00 \times 10^{-14}}{1.8 \times 10^{-5}} = 5.6 \times 10^{-10}$$

$$\frac{x^2}{(0.0500 - x)} = 5.6 \times 10^{-10}$$

$$x = [\text{OH}^-] = 5.3 \times 10^{-6}$$

$$\text{pOH} = 5.28$$

$$\text{pH} = 8.72 \quad (\text{NOT } 7)$$

4) Add another 0.1 mL NaOH

Total Vol. NaOH = 50.1 mL

$[\text{OH}^-] \approx$ conc. excess NaOH

$$\frac{0.0001 \text{ L} \times \frac{0.100 \text{ mol}}{\text{L}}}{0.1001 \text{ L}} = 9.99 \times 10^{-5} \text{ M}$$

OH^-

$$p\text{OH} = 4.0$$

$$p\text{H} = 10.0$$

c) Weak Base - Strong Acid

Calc. pH at the eq. pt.
when 10.0 mL of 0.36 M
ethylamine is titrated w. 0.12 M HCl



\therefore Vol. HCl at eq. pt. $\neq V_{0,\text{base}}$




Initially,

$$0.0100 \text{ L} \times \frac{0.36 \text{ mol}}{\text{L}} = 0.0036 \text{ mol} \\ \text{C}_2\text{H}_5\text{NH}_2$$

Transparency 122

Figure 17.10 pH curve for strong acid-weak base titration




Requires ? moles H^+ for neut'n.

D) Conclusions

- 1) Indicator must be chosen to change color at a pH close to eq. pt.
- 2) Use pH meter instead.
Graph pH vs. Vol. of titrant & estimate vol. corresponding to midpoint of steeply rising portion of curve.
- 3) Use titration curve to determine K_a of weak acid.
Find $V = \frac{1}{2} V_{\text{eq. pt.}}$,
 $\frac{1}{2}$ neutralized
 $\therefore \text{pH} = \text{p}K_a$

Figure 17.1 Calculating pH for a partially neutralized acid-base mixture



4) Weak Acid - Strong Base or
Weak Base - Strong Acid

a) initially weak acid or
weak base ionization

b) after add'n. of titrant
Buffer

c) at Eq. Pt.

Hydrolysis

d) conc's determined by
neut. rx. to completion
& then equil. rx. w.
common-ion

Transparency 124

Figure 17.12 Titration curve for Na_2CO_3 with HCl

